## 

Cabin specifications	<ul> <li>S9000 Neptune<sup>™</sup> submarine fire + smoke trainer (two cabins)</li> <li>Size: (LxWxH): 9,0m x 5,0m x 2,6m (30 x 16ft x 8.5ft)</li> <li>Weight: 4,700 kg + 2,600 kg (11,000 lbs + 6,000 lbs)</li> <li>Power: 400V(380V)/32A</li> <li>Cabin insulation</li> <li>Mineral wool (MW) (standard)</li> <li>Polyurethane foam (PU) / Polyisocyanurate (PIR) (optional) Wall: MW 0.57 (W/m<sup>2</sup>K), PIR 0.20 (W/m<sup>2</sup>K) Roof: MW 0.36 (W/m<sup>2</sup>K), PU 0.20 (W/m<sup>2</sup>K) Floor: MW 0.55 (W/m<sup>2</sup>K), PU 0.20 (W/m<sup>2</sup>K)</li> </ul>
Functionalities	<ul> <li>Electrical fire + smoke + short circuit effects</li> <li>Galley fire + smoke + functional switch</li> <li>Lithium-ion battery fire + smoke + glowing spot</li> <li>Stowage compartment fire + smoke</li> <li>Lavatory fire simulation + smoke</li> <li>Cabin smoke functionality</li> <li>Selectable fire training scenarios (manual/automatic)</li> <li>Programmable lesson plans (8 lesson plans)</li> <li>Adjustable interior lighting (0% - 100%)</li> <li>Adjustable training exercise timing</li> <li>Adjustable fire training difficulty (Level 1 – 5)</li> <li>Adjustable fire re-light timers</li> <li>Cabin (under water) sound</li> <li>Burning smell functionality</li> </ul>
Equipment	<ul> <li>One 10.2" portable iPad Instructor Operating Station (IOS)</li> <li>One 7" wall-mounted Instructor Operating Station (IOS)</li> <li>ARS1200 Automatic fire extinguisher refilling system</li> <li>Stainless steel red training fire extinguishers (three included)</li> <li>On-board air compressor with automatic draining</li> <li>On-board smoke generator unit</li> <li>Water filter and decalcifier unit</li> <li>Air conditioning provisions</li> <li>Air conditioning unit</li> </ul>
Safety systems	<ul> <li>Automatically regulated air extraction system</li> <li>Automatic gas-leak test</li> <li>Dräger gas detection system</li> <li>Four infra-red gas detection transmitters</li> <li>Five maintenance-free dry-burner units with pilot burner</li> <li>Fire control sensors</li> <li>Over-temperature control system</li> <li>Airflow monitoring system</li> <li>Emergency stop system</li> <li>Evacuation and orientation lighting</li> <li>Panic escape handles on all doors</li> <li>Optical and acoustic alarm</li> </ul>

## 

	Anti-slippery safety floor
System control functionalities	<ul> <li>Airflow fault indication</li> <li>Smoke fluid low indication</li> <li>Gas low indication</li> <li>Gas empty indication</li> <li>Pilot burner fault indication</li> <li>Main burner fault indication</li> <li>Water supply fault indication</li> <li>Refilling station fault indication</li> <li>Leak-test ok/fault indication</li> <li>Decalcifier fault indication</li> <li>Routine maintenance indication</li> </ul>

© Flame Aviation B.V. 2020 - Specification is reserved for changes

Standard

 $\circ$  Optional