

<p>Cabin specifications</p>	<p>V7000 Brigade™ + V7000 Brigade™ VIEW (one cabin)</p> <ul style="list-style-type: none"> • Size: (LxWxH): 9,0m x 2,4m x 2,6m (30ft x 8ft x 8.5ft) • Weight: 4,700 kg (11,000 lbs) • Power: 400V(380V)/32A <p>V9000 Commander™ (XR) (two cabins)</p> <ul style="list-style-type: none"> • Size: (LxWxH): 9,0m x 4,8m x 2,6m (30ft x 16ft x 8.5ft) • Weight: 4,700 kg + 2,600 kg (11,000 lbs + 6,000 lbs) • Power: 400V(380V)/32A <p>Cabin insulation</p> <ul style="list-style-type: none"> • Mineral wool (MW) (standard) ○ Polyurethane foam (PU) / Polyisocyanurate (PIR) (optional) <p>Wall: MW 0.57 (W/m²K), PIR 0.20 (W/m²K) Roof: MW 0.36 (W/m²K), PU 0.20 (W/m²K) Floor: MW 0.55 (W/m²K), PU 0.20 (W/m²K)</p>
<p>Functionalities</p>	<ul style="list-style-type: none"> • Laptop fire + smoke + glowing spot • Oven fire + smoke + functional master galley switch • Seat fire + smoke + short circuit effects • Luggage compartment fire + smoke • Lavatory waste bin fire + smoke + glowing spot + smoke indication light • Smartphone fire simulation • Tablet fire simulation ○ Under-seat fire simulation + smoke • Cabin smoke functionality • Manual coffee pot refilling unit ○ Automatic coffee pot refilling unit • Selectable fire training scenarios (manual/automatic) • Programmable lesson plans (8 lesson plans) • Adjustable interior lighting (0% - 100%) • Adjustable training exercise timing • Adjustable fire training difficulty (Level 1 – 5) • Adjustable fire re-light timers ○ Air conditioning outlet smoke functionality (optional) ○ Cabin panic sound (standard in XR-version) ○ Hot spots in lavatory door (standard in XR-version) ○ Hot spots in luggage bin (standard in XR-version) ○ Burning smell (standard in XR-version)
<p>Equipment</p>	<ul style="list-style-type: none"> • One 10.2" portable iPad Instructor Operating Station (IOS) • One 7" wall-mounted Instructor Operating Station (IOS) • ARS1200 Automatic fire extinguisher refilling system • Stainless steel red training fire extinguishers (three included) • On-board air compressor with automatic draining • On-board smoke generator unit • Water filter and decalcifier unit • Air conditioning provisions ○ Air conditioning unit

<p>Safety systems</p>	<ul style="list-style-type: none"> • Automatically regulated air extraction system • Automatic gas-leak test • Dräger gas detection system • Four infra-red gas detection transmitters • Five maintenance-free dry-burner units with pilot burner • Fire control sensors • Over-temperature control system • Airflow monitoring system • Emergency stop system • Evacuation and orientation lighting • Panic escape handles on all doors • Optical and acoustic alarm • Anti-slippery safety floor
<p>System control functionalities</p>	<ul style="list-style-type: none"> • Airflow fault indication • Smoke fluid low indication • Gas low indication • Gas empty indication • Pilot burner fault indication • Main burner fault indication • Water supply fault indication • Refilling station fault indication • Leak-test ok/fault indication • Decalcifier fault indication • Routine maintenance indication

© Flame Aviation B.V. 2020 - Specification is reserved for changes

- Standard
- Optional